

**COMPACT, INDUSTRIAL
THERMAL CAMERA**



Ceres V 640 Series

Uncooled microbolometer camera for high-resolution thermal imaging



UNCOOLED MICROBOLOMETER CAMERA FOR HIGH-RESOLUTION THERMAL IMAGING

KEY FEATURES

- ◆ Compact and high-resolution
- ◆ Superior on-board thermographic performance (optimized image quality)
- ◆ GenICam compliant
- ◆ Uncooled operation
- ◆ Flexible optical mount and lens options¹

The Ceres V 640 series is based upon the Dione 640 OEM thermal imaging core with 640x480 pixels and 12 μm pixel pitch. Thanks to the state-of-the-art microbolometer detector and on-board image processing, the camera offers superior thermal imaging capabilities.

The Ceres V 640 camera outputs full frame images at 60 Hz via either a CameraLink or GigE Vision interface - all GenICam compliant. The compact size, excellent image quality and GenICam compliant interfacing allow for easy integration in demanding industrial, scientific and security thermal imaging applications.

Ceres V 640 Series

EU based supplier



KEY PERFORMANCES

Image format/Pixel pitch	640 x 480 pixels / 12 μ m
Integration type	Rolling Shutter
Spectral range	8 -14 μ m
Max frame rate (full frame)	60 Hz
Power consumption	4 W (GigE); 3.5 W (CL)
Power supply voltage	DC 12 V

FUNCTIONS & INTERFACES

Digital output format	GigE; CL
Operating temperature range (housing temperature)	From -40 °C to +70 °C
Storage temperature	From -40 °C to +85 °C
Detector NETD	<50 mK(at 30Hz, 300K, F/1); <40 mK (at 30 Hz, 300 K, F/1), available upon request
Shock / Vibration	40 g, 11 ms, MIL-STD810G/5 g (20 to 2000 Hz), MIL-STD810G

PRODUCT SELECTOR GUIDE

XEN-000786 [Ceres V 640 GigE 50 mK (60 Hz)]	XEN-000724 [Ceres V 640 GigE 50 mK (9 Hz)]
XEN-000788 [Ceres V 640 GigE 40 mK (60 Hz)]	XEN-000725 [Ceres V 640 GigE 40 mK (9 Hz)]
XEN-000784 [Ceres V 640 CL 50 mK (60 Hz)]	XEN-000727 [Ceres V 640 CL 50 mK (9 Hz)]
XEN-000787 [Ceres V 640 CL 40 mK (60 Hz)]	XEN-000728 [Ceres V 640 CL 40 mK (9 Hz)]

¹Available with different lens interfaces. For more information, contact us at sales@xenics.com.

sales@xenics.com



xenics.com

Xenics
Photonis Group

© Xenics. XDS032. The information furnished is believed to be accurate and reliable, but is not guaranteed and is subject to change without notice. No liability is assumed by Xenics for its use. Performance data represents typical characteristics as individual product performance may vary. Customers should verify that they have the most current Xenics product information before placing orders. No claims or warranties are made as to the application of Xenics products. Texts and pictures may not be considered as contractually binding. This document may not be reproduced, in whole or in part, without the prior written consent of Xenics.